

# LANTH400

## Installation Instructions

Combine Header Trailer Hitch for JD® 70 & "S" Series Combines



**270 West Park Avenue**

**Huron, SD 57350**

**866-526-5682**

## Numerical Parts List

<b><i>Part Numbers</i></b>	<b><i>Description</i></b>	<b><i>Quantity</i></b>
LANTH401	Hitch Weldment	1
LAN20180*	M20 x 190mm Long Bolt	5
LAN1Q79*	M20 Nylon Lock Nut	5
REDWU58	¾" flat washer	10

## Pictorial Parts List



# Preparation



Engage parking brake and turn off engine.

## Using Existing Holes

... elevate the  
... of the middle

in Figure 1.1.

Figure 1.1

**Refer to Figure 1.2**

- 1.3 Raise hitch (LANTH401) into place and align holes in hitch mounting plates with four holes in axle frame.
- 1.4 Install five provided bolts (LAN20180) as shown in Figure 1.2. \*One bolt faces the opposite way as the other four.\* Tighten all hardware.
- 1.5 Lower combine to ground. Remove jack and all tools.

**Figure 1.2**



For further technical information contact Lankota: 866-526-5682